

The Nest Healesville Accommodation – Air Conditioner Controller

LCD display for an easy overview of the operation status

Press once each time you need to activate Eco Patrol. For even more savings, press a second time to access Eco Patrol Mode Two. Please refer to Operating Instructions to find out more

Adjusts the fan speed

Recommend AUTO

Toggles between AUTO, HEAT, COOL and DRY setting mode

Recommend AUTO

Sets the Airflow

Recommend AUTO

Sets the actual time (hour and minute)

Activates the air-purifying function even when the air conditioner is switched off

Recommend OFF


Press up or down to set the temperature

Maintain higher level of Relative Humidity

Stronger airflow to cool the room more quickly

Reduces the indoor operating sound

Sets the 24-hour ON & OFF Timer or 24-hour Dual ON & OFF Timer



Wireless